Hardware: Option

Door opening with the P7000/P7050

DOOR OPENING WITH THE P7000/P7050

Up to 4 serial readers can be connected to the P7000/P7050 Terminal for door opening. In this way, you can implement a door opening within a time recording system without access software.

FUNCTION: Door opening

Prerequisite for door opening with the P7000/P7050 is the MTZ® BS from version 8.2.

Fig. P7000 with connected access reader M600

► FEATURES

- Connection of up to 4 serial readers and up to 4 IO modules
- Power supply of reader and door strike via the terminal
- RS485 2-wire connection of readers
- Door opening without access software
- Door opening via card/fingerprint, contact or PIN code
- 4 weekly programmes
- Permanent door opening via function keys or contact
- Door locking via cntact

▼ IO MODULE

MH9151	IO Module for M readers

▼ READERS FOR P7050

MH9728	M650, Fingerprint Identification, MIFARE Classic/DESFire, surface-mounted
MH9731	M660, Fingerprint Identification, MIFARE Classic/DESFire, surface-mounted

▼ READERS FOR P7000

MH9712	M600, MIFARE Classic / DESFire, surface-mounted
MH9713	M600, LEGIC prime / advant, surface-mounted
MH9714	M600, MIFARE Classic / DESFire, flush-mounted
MH9715	M600, LEGIC prime / advant, flush-mounted
MH9716	M605, MIFARE Classic / DESFire, outdoor, surface-mounted
MH9717	M605, LEGIC prime / advant, outdoor, surface-mounted
MH9718	M610, MIFARE Classic / DESFire, surface-mounted
MH9719	M610, LEGIC prime / advant, surface-mounted
MH9720	M610, MIFARE Classic / DESFire, flush-mounted
MH9721	M610, LEGIC prime / advant, flush-mounted
MH9722	M615, MIFARE Classic / DESFire, outdoor, surface-mounted
MH9723	M615, LEGIC prime / advant, outdoor, surface-mounted

Attention: When extending an existing system, a firmware update (from 1.02) may be necessary.